

M3 Mobile SL20

Accessory Guide



1-Slot Cradle

Charging only

2-Slot Cradle

Charging & Ethernet

Charging & USB



MISCELLANEOUS

Battery (2 types)

USB Cable

Boot / Hand strap

Screen protector



8-Slot Cradle (2 types)

Charging & Ethernet

Charging Only



Trigger Handle



Wearable

Ring trigger

Ring scanner charging cradle

Holster / Armband

* The above list may be added or changed.

1-Slot & 2-Slot Cradle



SL20-1CRD-C00

SL20 1-Slot charging only cradle for 1xSL20.

SL20-2CRD-CC0

SL20 2-Slot charging & USB(Client) cradle for 1xSL20 & 1xSL20 spare battery.

SL20-2CRD-EC0

SL20 2-Slot charging & Ethernet cradle for 1xSL20 & 1xSL20 spare battery.

1 & 2-Slot Cradles requires power supply: SL20-PWSP-2EU, SL20-PWSP-2KR, UNIV-PWSP-2US, UNIV-PWSP-2UK, UNIV-PWSP-2CN, UNIV-PWSP-2AU ; included DC Line and AC Cord

8-Slot Cradle



SL20-8CRD-C00

SL20 8 slot charge only cradle for 4xdevice & 4xspare battery.

SL20-8CRD-E00

SL20 8 slot charging & Ethernet cradle for 4xdevice & 4xspare battery.

8-Slot Cradles requires power supply: 100~240VAC, 12VDC, 7A.
UNIV-PWSP-8KR, UNIV-PWSP-8EU, UNIV-PWSP-8US, UNIV-PWSP-8UK, UNIV-PWSP-8CN,
UNIV-PWSP-8AU ; included DC Line and AC Cord

Trigger Handle



SL20-TRIG-S00

Trigger Handle for SL20.

Easily attaches to SL20 top housing
Charging is possible immediately without removing the trigger when using the cradle.
Use SL20 by contacting the rear I/O connector pin.

Rubber Boot



SL20-BOOT-01

Rubber boot for SL20.

Easily attaches to SL20 top housing
Charging is possible immediately without removing the Boot when using the cradle.
(When charging SL20 with Rubber boot, remove the charging pocket inside the cradle.)

Ring Scanner & Cradle



UNIV-WERS-U20

Ring scanner SE4710, Bluetooth type *Using the M3 Ring Scanner Application

UNIV-WERS-U10

Ring scanner SE2707, Bluetooth type *Using the M3 Ring Scanner Application

UNIV-WERC-U00

Ring scanner charging cradle (5V USB adapter sold separately, USB cable is included)

UNIV-WERC-C00

USB Cable for Ring scanner Charging cradle, 1.5M

Arm Band & Holster



UNIV-CASE-FSH

SL10, SL10K, SL20, SM10, SM15, SM20 Fabric Holster with Strap, belt

UNIV-CASE-FAB

SL10, SL10K, SL20, SM10, SM15, SM20 Arm Band

Hand Strap

SL20-STRP-S50

Hand strap for SL20 (50 pcs)

SL20-STRP-S10

Hand strap for SL20 (10 pcs)

Battery

SL20-BTDO-SHF

NFC Battery Door for SL20 when using Standard Battery

SL20-BATT-S30

SL20 Charging Standard Capacity Spare Battery 3,000mAh

SL20-BTDO-EHF

NFC Battery Door for SL20 when using Extended Battery

SL20-BATT-E50

SL20 Charging Extended Capacity Spare Battery 5,000mAh

Screen Protector

SL20-SCPR

Bullet proof Screen Protector for SL20.