



US20 Series Accessories Guide







US20-2CRD-CU0

2-Slot Charging Cradle

US20 2-Slot charging & USB host client cradle for 1xUS20 & 1xUS20 spare battery. Requires power supply (US20-PWSP-2XX; sold separately)

US20-2CRD-EC0

2-Slot Ethernet Cradle US20 2-Slot charging & Ethernet USB client cradle for 1xUS20 & 1xUS20 spare battery. Requires power supply (US20-PWSP-2XX; sold separately)



US20-PWSP-2AU

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2-Slot cradle with US20. Includes AU power cord.

US20-PWSP-2CN

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2-Slot cradle with US20. Includes CN power cord.

US20-PWSP-2EU

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2-Slot cradle with US20. Includes EU power cord.

US20-PWSP-2KR

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2-Slot cradle with US20. Includes KR power cord.

US20-PWSP-2UK

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2-Slot cradle with US20. Includes UK power cord.

US20-PWSP-2US

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2-Slot cradle with US20. Includes US power cord.







US20-5CRD-C00

5-Slot Charging Cradle

US20 5-Slot charging only cradle for 5 x US20. Requires power supply (US20-PWSP-5XX; sold separately)

US20-5CRD-E00

5-Slot Ethernet Cradle US20 5-Slot charging & Ethernet cradle for 5 x US20. Requires power supply (US20-PWSP-8XX; sold separately)

US20-5CRD-C00-MT

5-Slot Charging Cradle for 4 x US20 & 4 Batteries US20 5-Slot charging only cradle for 4 x US20 & 4 Batteries. Requires power supply (US20-PWSP-5XX; sold separately)

US20-5CRD-E00-MT

5-Slot Ethernet Cradle for 4 x US20 & 4 Batteries US20 5-Slot charging & Ethernet cradle for 4 x US20 & 4 Batteries. Requires power supply (US20-PWSP-5XX; sold separately)

US20-PWSP-5AU

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Slot cradle with US20. Includes AU power cord.

US20-PWSP-5CN

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Slot cradle with US20. Includes CN power cord.

US20-PWSP-5EU

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Stot cradle with US20. Includes EU power cord.

US20-PWSP-5KR

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Slot cradle with US20. Includes KR power cord.

US20-PWSP-5UK

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Slot cradle with US20. Includes UK power cord.

US20-PWSP-5US

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Slot cradle with US20. Includes US power cord.







US20-TRIG-S00

Scanning Trigger Handle for US20

- Reduce wrist fatigue when workers are using terminals for long time.
- Save time by counting stocks in warehouse.
- The design is ergonomically made by measurement in mechanical team.
- The trigger handle has essential functions properly in industrial environments.
- The US20 and Tigger handle can be removed quickly and easily, depending on the situation.



US20-VCRD-C01

US20 Vehicle Charging & USB Cradle by M3 mounted USB cable. Requires vehicle mount(UNIV-RAMS-0X or UNIV-RAMT-0X; sold separately) ** Cigar Jack Gender sold separately

To use forklift cradle, you need the following products, and we will open the detailed SKU number later.

- Vehicle mount
- Clamp base
- Voltage Power Converter
- Forklift power input cable

* Launching will be ready soon



Battery Charger



US20-4BTCH-C00

4-Slot Battery Charger

M3 Battery charging station for US20, 4-Slot Battery Charging Station. Requires power supply (US20-PWSP-2XX; sold separately)

US20-20BTCH-C00

20-Slot Battery Charger 5-Slot charging cradle for 20 Batteries (5 x 4 Slot Battery Charging Station). Requires power supply (US20-PWSP-5XX; sold separately)



US20-PWSP-2US / US20-PWSP-2UK / US20-PWSP-2KR / US20-PWSP-2EU / US20-PWSP-2CN / US20-PWSP-2AU

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Slot cradle with US20. Includes US/ UK/ KR/ EU/ CN / AU power cord.

US20-PWSP-5US/US20-PWSP-5UK/US20-PWSP-5KR/ US20-PWSP-5EU/US20-PWSP-5CN/US20-PWSP-5AU

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Slot cradle with US20. Includes US/ UK/ KR/ EU/ CN / AU power cord.



US20-BATT-E67 (US20-BATT-E67-S10): US20 Fast Charging Extended Capacity Spare Battery 6,700mAh (10 pcs)

US20-BATT-S26(US20-BATT-S26-S10): US20 Fast Charging Standard Capacity Spare Battery 2,600mAh (10 pcs)

MISCELLANEOUS



USB cable, 1.2M, C to A plug for US20

Requires power supply (US20-PWSP-U00; sold separately)






US20-STRP-(S10 or S50) Hand strap for 45° Scan US20 (10 pcs or 50 pcs) **US20-STRP-(E10 or E50)** Hand strap for 0° Scan US20 (10 pcs or 50 pcs)



US20-STYL Spare Stylus with tether for US20



Choice of US20 Functionality for Convenient Use



The following are not accessories, but SKUs are different for each scanner.



Long Range Scanner Able to read maximum 21.4 meters * The SKU of the scanner is divided into 2D and LR



USE IT THIS WAY It's the most complete and useful way to use it.

